WO# 7191472 / FWO# 80140878
Replace existing 1PH on Culver St 556 Spacer Cable
Reconductor 3PH on Deming St with 556 Spacer Cable

WO# 7191472 / FWO# 80140878
WO# 7013544 / FWO# 80133775

WO# 7012531 / FWO# 80133724
Reprogram 7L86-92T to function
As J Switch 7L86-10J
Install wedge connectors and In-line switches

WO# 7013364 / FWO# 80133768
Install 2-way TR 7L89-93T Pole 4888
Install switches at pole 4887

Change Cortland Way
To Phase C

Change Apple Hl
To Phase C

Change Rockledge Dr
To Phase A

WO# 7013544 / FWO# 80133775
Replace existing 1PH with
556 Spacer Cable

Pole 568
AT&T V-Rad Location

WO# 7012322 / FWO# 80133714
Install SR 6A3-72S
New Frontier Pole Location

WO# 7012665 / FWO# 80133727
Install MR 6A3-80M Pole 3407

WO# 7011724 / FWO# 80133691
Replace 6A3 Get-a-way cable with 1000MCM CU

6A Sub-Station
Beckley Rd
Berlin